

# TOYOTA 6 CYL

<b>ALTEZZA</b>	02-ON		<b>AUTO + MANU</b>	Tuned		
L6	PETROL	2997cc	2JZ-GE	Tri Y		<b>ETO9493</b>
GITA Model Check 1G-FE Mtr				Gaskets	GK9259	

<b>LANDCRUISER</b>	80-ON	FJ62 - FJ75	<b>AUTO + MANU</b>	Tuned		
L6	PETROL	3955cc	3F	Tri Y	41	<b>PH12630</b>
Runs Inside Chassis				Gaskets	GK9194	

<b>LANDCRUISER</b>	80 - 89	HJ45 - HJ75	<b>MANU ONLY</b>	Tuned		
L6	DIESEL	4.0L	2H	Tri Y	41	<b>PH12640</b>
				Gaskets	GK9155	

<b>LANDCRUISER</b>	84 - 89	BJ70 - 73		Tuned		
L4	DIESEL	3.4L	3BMTR	Tri Y		<b>ETO2158</b>
<b>Not Available</b>				Gaskets	(HSM51)	

<b>LANDCRUISER</b>	90-98	75-79 SERIES	<b>AUTO + MANU</b>	Tuned		
L6	DIESEL	4.2L	1HZ	Tri Y	41	<b>PH12700</b>
Requires Base Pipe PHB75 (has flex)				Gaskets	GK9214	

<b>LANDCRUISER</b>	90-95	80 SERIES	<b>AUTO + MANU</b>	Tuned		
L6	PETROL	3955cc	3F-E	Tri Y		<b>ETO2558</b>
				Gaskets	GK9194	

<b>LANDCRUISER</b>	90-97	80 SERIES	<b>AUTO + MANU</b>	Tuned		
L6	DIESEL	4.2L	1HZ	Tri Y	41	<b>PH12700</b>
Requires Base Pipe PHB80 (has flex)				Gaskets	GK9214	

<b>LANDCRUISER</b>	92-ON	80 SERIES	<b>AUTO + MANU</b>	Tuned		
L6	PETROL	4476cc	1FZ-FE 24V	Tri Y	41	<b>PH12650</b>
Requires Base Pipe PHB80P (no flex)				Gaskets	GK9307	

<b>LANDCRUISER</b>	98-03	100 SERIES	<b>AUTO + MANU</b>	Tuned		
L6	DIESEL	4.2L	1HZ	Tri Y	41	<b>PH12700</b>
Requires Base Pipe PHB100 (has flex)				Gaskets	GK9214	

<b>LANDCRUISER</b>	98-03	100 SERIES	<b>AUTO + MANU</b>	Tuned		
L6	PETROL	4476cc	1FZ-FE 24v	Tri Y	41	<b>PH12650</b>
Requires Base Pipe PHB100P (no flex)				Gaskets	GK9307	

# TOYOTA V6+V8

<b>4 RUNNER</b>	92-ON	4WD	AUTO + MANU	Tuned	<b>ETO2761</b>
V6	PETROL	3.4L 5VZ-FE		Tri Y	
Includes Y Pipe				Gaskets	GK9197

<b>LANDCRUISER</b>	98-03	100 SERIES	AUTO ONLY	Tuned	
V8	PETROL	4663cc 2UZ-FE 32v	DOHC	Tri Y	<b>PH12680</b>
				Gaskets	GK9308

<b>LANDCRUISER</b>	92 - 98	800 SERIES		Tuned	
L6	PETROL	FZJ80 4.5	DOHC	Tri Y	<b>ETO9329</b>
Check PH12650				Gaskets	